

X16  
~~A18~~ disassembly tutorial

Remove the four screws at the corners



Remove other screws



After separating the back cover, the surrounding copper pillars can be removed



